

ES1-A, ES2-A, ES3-A, ES4-A

POINTER PLATES




ES1-A



ES2-A




ES3-A ES4-A



ES1-A ES1N-A-SUS : ϕ 3.5 Mounting-Hole Marks
 ES2-A ES2N-A-SUS : ϕ 3.5 Mounting Holes

ES1-A ES1N-A-SUS
 ES2-A ES2N-A-SUS



ES3-A ES4-A

Type	Body
ES1-A ES2-A	Aluminum (A1050P) Graduations etched
ES1N-A-SUS ES2N-A-SUS	Stainless steel (SUS304) Graduations etched
ES3-A ES4-A	Stainless steel (SUS304)

ES1-A & ES2-A


Adhesive-Mounting Style (with ϕ 3.5 Marks)				Screw-Mounting Style (with ϕ 3.5 Holes)				No. of ϕ 3.5 Marks or Holes
Aluminum		Stainless Steel		Aluminum		Stainless Steel		
Part Number	Weight (g)	Part Number	Weight (g)	Part Number	Weight (g)	Part Number	Weight (g)	
ES1-A	0.3	ES1N-A-SUS	0.9	ES2-A	0.3	ES2N-A-SUS	0.9	2

ES3-A & ES4-A



Adhesive-Mounting Style (with ϕ 3.5 Holes)		Screw-Mounting Style (with ϕ 3.5 Holes)		No. of ϕ 3.5 Holes
Part Number	Weight (g)	Part Number	Weight (g)	
ES4-A	0.6	ES4-A	0.6	2

How To Use

ES1-A & ES2-A



ES3-A & ES4-A



The projected pointer of the Pointer Plate allows reading values easily.

The projected pointer of the Pointer Plate can be bent in parallel with the Scale Plate, for clearer indicating.

Bend the pointer tip of ES3-A firstly before sticking it on.